



Woodland  
Lifestyle

UPDATED: 14/05/24

---

# FloorMuffler Glue guide

# NZ



# floorMuffler®

## DOUBLE GLUE DOWN INSTALLATION INFORMATION NZ

The adhesives below have been tested and approved by the respective manufacturers for installation of the floorMuffler® underlayments. Woodland Lifestyle has not independently verified this information. Contact the adhesive manufacturer directly to obtain their installation instructions and warranty information prior to use

MANUFACTURER	ADHESIVE: <i>Underlayment to Substrate</i>	ADHESIVE: <i>Engineered Wood to Underlayment</i>	ADHESIVE: <i>LVT Tile/Plank to Underlayment</i>	TROWEL SIZE
<b>Mapei adhesives: P: 09 921 1994 W: <a href="http://www.mapei.com/nz">www.mapei.com/nz</a></b>				
Mapai	Eco 380 Ultrabond	Ultrabond Eco Fix	Ultrabond Eco 380	*
Mapai	Ultrabond Eco Fix	-	Ultrabond Eco V4 Evolution	*
Mapai	Ultrabond Eco V4 Evolution	-	Ultrabond Eco Fix	*
<b>Uzin adhesives: P: 03 379 7067 W: <a href="http://www.giltedge.co.nz">www.giltedge.co.nz</a></b>				
Uzin	2000S		68T 2000S (Resilient sheet)	*
				*
<b>Bostik Adhesives: P: 09 257 3584 W: <a href="http://www.bostik.com/newzealand/en_NZ">www.bostik.com/newzealand/en_NZ</a></b>				
Bostik	Bostik 3 in 1	Bostik 3 in 1		*
Bostic	Ultra set SF	Ultra set SF		*
<b>Selleys: P: 0800 735 539 W: <a href="http://www.selleys.co.nz">www.selleys.co.nz</a></b>				
Selleys	Timberflex	Timberflex		*

**\*ALWAYS speak to respective adhesive manufacturer directly for proper trowel recommendations.**